

# Trimming Tool Use Guide

10065

## 1. Product components

This trimming tool will be shipped with 8 poles made of epoxy resin

- 1 top pole & saw head
- 1 variable diameter pole
- 5 middle poles and
- 1 hand pole
- two bag




## 2. Specification

Name	Pruner Saw
Weight(gross)	12.45lbs (5.6Kg)
Material	Pole: epoxy resin Handle: Rubber Blades: 45# steel
Maximum length	26 feet (8m)
Shipping size	107cm*22cm*10cm
Ideal for	Overhang branch trimming

## 3. Introduction


Pruner saw is a useful trimming kit, ideal for urban landscape greening, lawn and garden, orchard farm and park service. With this pruner saw, you can get your job done easily, efficiently and safely.



手動剪枝工具

高枝剪 / 2

## 4. Replace the pruning saw blade



Tips: the steps of removing/ installing the pruning saw blade, the removal/installation is reversible.

## 5. Product operation



1 Connect the pruning saw

2 Connect the length of the pruning saw bar as needed

3 The operation sample

## 6. Care instruction

- Please make sure all trimming components are ready and working well before use. Better to post a warning notice on the trimming site.
- Do screw up the poles when in use. Recommended to trim the overhang branches from downside to upside to avoid blocking the saw.
- Cutting Diameter is up to 3.9inches (about 10cm).

## 7. Maintenance tips

- It's recommended to clean the resin on the saw and blades using a piece of cloth soaked with oil each time after use.
- Better place the pruner somewhere dry and apply anti-rust oil to it.

If you have any question, feel free to contact our Customer Service Line Email: [andahongtai123@hotmail.com](mailto:andahongtai123@hotmail.com)